



BT PTT key

Discreet PTT Car Key



The Bluetooth wireless PTT key comes in the shape of a car key that uses BLE 5.0 technology to remote 3 buttons that can be configured from an MCPTT or POC application installed on a smartphone. It is compatible with both Android and iOS.

It can be used discreetly by hand, and the 3 buttons can be used to converse on 2 group calls and launch an emergency one.

The PTT car key is designed for use in outdoor environments and is IP54-rated.

It is powered by an easily replaceable CR2032 battery, giving it a battery life of over 400 hours in nominal permanent connection mode.

An automatic shutdown system is built in as soon as the smartphone is no longer within range of the key.

The Bluetooth wireless PTT key can be updated and programmed using Bluetooth PC software.

The electronics and software are developed entirely by TPL Systèmes' teams in France.

