



The body camera and its acquisition server

It consists of a body camera, docking station and management server, the latter being hosted within the company or in the cloud.

The **T2 Endura bodycam** prevents, reduces and records incidents at the frontline. It protects and supports professionals to do their daily work for the general public more safely.

The lightweight **T2 Endura bodycam** is easy to wear and use by professionals in various industries, such as law enforcement, private security, public transport, fire brigades, healthcare, retail and delivery. The ZEPCAM videos with audio and GPS are recorded, offloaded and stored encrypted to be viewed and managed with ZEPCAM Manager Software by the authorised staff only.

Selected videos can be shared securely with all metadata to the justice chain or with other video management or reporting systems. The entire videoprocessing is configurable for full compliance with all applicable privacy laws and organisational procedures. ZEPCAM videos will therefore be accepted as evidence in legal procedures in every country.

- **On-premise solution:** the camera management server is installed on the customer's own infrastructure. It enables automatic downloading of videos to the server, playback/downloading of videos after the fact, remote camera parameterization and consultation of logs. This solution works with 4 and 8-position loading and acquisition stations.

- **Cloud solution:** the camera management server is installed in the Cloud. It enables automatic downloading of videos to the dedicated Cloud environment, playback/downloading of these videos after the fact, remote camera parameterization and log consultation. This solution works with 4 and 8-position charging and acquisition stations.

Both solutions enable automated and manual blurring of faces, objects, and number plates, as well as sound removal.



European technology, 100% GDPR compliant

Features

T2 Endura bodycam specifications

- Video quality : HD (720p), Full HD (1080p)
- Video format : MP4, H.264
- Photo format : Max 16 MP, JPG
- IP class : IP 65 (rain & dust proof)
- Angle of view : 140 degrees
- Audio : Built-in microphone
- Storage : 64GB internal storage
- Recording time : Up to 14.5 hours
- Temperature : -20 to +60 degrees Celcius
- Night view : Built-in infrared light
- Encryption : AES 256 encryption
- Size : 72x56x24 mm (HxWxD)
- Weight : 115 gram
- Mounts : Various

Docking station specification

- Capacity : 4 or 8 bay docking station
- Charging time : On average 2.5 hours
- Offload speed : Offload to dock 480 MB/sec
- Connection : Gigabit ethernet to server, Offload to server up to 1 GB/sec
- Buffering : Onboard SSD storage (256Gb/512Gb)
- Power : 30V (6W idle 50W full charge)
- Status : LED feedback status bodycam LCD screen for status info
- Authentication : Bodycam or officer ID configurable
- Encryption : AES 256 bit encryption
- Size : 70x640x90 mm (HxWxD)
- Dynamic User-ID and authentication : Keypad, RFID Reader, HDMI LCD screen

